# Beep, Beep: Making Sense of Clinical Anesthetic Monitors

### Lindsey Culp Snyder, DVM, MS, DACVA

## University of Wisconsin

## Madison, WI

#### 1. Why do we monitor anesthesia?

- a. Patient's normal physiology is altered by anesthetic drugs
- b. Compensatory mechanisms are diminished by anesthetics
- c. Concurrent diseases will alter normal physiology
- Monitoring improved the patient's success by allowing for informed, timely responses to changes in status
  I. Proactive decisions versus reactive decisions
- e. Provides a good reference for additional anesthetic procedures
- 2. What do we need to know before we can monitor properly?
  - a. Pharmacology of anesthetic drugs
  - b. Pharmacology of current medications
  - c. Normal physiology
  - d. ASA status
  - e. Anesthetic record
  - f. Monitors
    - I. What information they provide
    - II. What information we can interpret from their use
- 3. How do we develop a monitoring plan?
  - a. Develop a plan based on body systems
  - b. Considerations of health
    - I. Current health status
    - II. Concurrent diseases
  - c. Procedure to be done
  - d. Available monitoring devices
  - e. Plan to monitor more than one system and more than one variable per system
- 4. Methods
  - a. Indirect/noninvasive
    - I. Readily apparent variables
    - II. Noninvasive testing
    - III. Easily attainable, no advanced skills needed, easily reproducible
    - IV. Minimal secondary complications
    - V. Limited amount of data to be collected
  - b. Direct/invasive
    - I. Placing instruments inside the body
    - II. Increased data to be obtained
    - III. Less error in data that is collected
    - IV. Secondary complications
    - V. Advanced knowledge and skill needed
- 5. Central nervous system
  - a. Anesthesia requires CNS depression
  - b. Movement on the table
  - c. Diligent monitoring helps maintain a stable plane of anesthesia
  - d. Monitor reflex activity
    - I. Eye signs (palpebral, corneal, pupil location)
    - II. Pedal reflexes
  - e. Skeletal muscle relaxation
  - f. EEG/BIS
  - g. End-tidal anesthetic gas concentration
    - I. MAC
- 6. Respiratory system
  - a. Readily available data with obsevation
    - I. Rate (Stethoscope, breathing frequency monitors, pulse oximeter, etc.)
    - II. Pattern
    - III. Tidal volume changes
  - b. Pulse oximeter
    - I. Pulse rate

- II. Oxygen saturation (SpO2)
- III. Does not measure adequacy of ventilation!!!
- IV. Needs a pulsatile signal for an accurate reading, therefore errors can occur with hypothermia, hypotension, changes in vascular resistance
- V. Needs an understanding of the oxyhemoglobin dissociation curve for proper interpretation
- c. End-tidal carbon dioxide monitor (CO2)
  - I. Most valuable monitor for assessing the adequacy of ventilation !!!
  - II. Capnometer vs. capnograph
  - III. Estimation of the alveolar CO2 concentration
  - IV. Must use when controlling ventilation
  - V. Normal value is 40 mmHg
- d. Gas monitors
- e. Spirometry
  - I. Quantitate the tidal volume
- f. Hemoglobin concentrations
- g. Blood gas analysis
- Cardiovascular system
- a. Heart rate

7.

- I. Direst palpation
- II. Ultrasonic Doppler
  - 1) Piezoelectric crystal
  - 2) Amplifies the sound of blood flow under the crystal
  - 3) Can be used for blood pressure as well
- III. Pulse oximeter
- b. Peripheral perfusion
  - I. Function of arterial blood pressure and local vasomotor tone
  - II. Normal capillary refill time of 1-2 seconds
  - III. Urine production can be used
- c. Central venous pressure (CVP)
  - I. Assessing patient's blood volume
  - II. Affected by blood volume, vascular tone, cardiac contractility, heart rate, an non-cardiac factors (body position)
- d. Blood pressure!
  - I. Most important monitoring modality for assessment of the cardiovascular system
  - II. Can be made either directly or, more commonly, indirectly
  - III. Oscillometric monitors
    - 1) Slowly releases air from the cuff (placed over a peripheral artery) until arterial pulsations are detected by the monitor and are then displayed by the monitor
    - 2) Display the systolic, diastolic and mean blood pressure
    - 3) Inaccurate in smaller patients and at low blood pressures, but should accurately reflect trends in the BP
    - 4) Heart rate as well
  - IV. Ultrasonic Doppler
    - 1) Doppler crystal placed over a peripheral artery
    - 2) Appropriately sized cuff placed proximal to the crystal
    - 3) With the use of a sphygmomanometer air is slowly released from the cuff until a pulse is heard on the Doppler
    - 4) The pulse corresponds most closely to the systolic blood pressure in dogs and the mean arterial blood pressure in cats
    - 5) Doppler apparatus can be inaccurate at lower blood pressures
  - V. Direct arterial BP
  - VI. Arterial catheter.
  - VII. Accurate quantitative arterial BP value and a qualitative representation of the arterial pulse waveform
  - VIII. Systolic, diastolic, and mean arterial BP's easily measured and displayed using this method.
  - IX. Very accurate